
Two-Qubit Gate of Combined Single-Spin Rotation and Interdot Spin Exchange in a Double Quantum Dot

R. Brunner, Y.-S. Shin, T. Obata, M. Pioro-Ladrière, T. Kubo, K. Yoshida, T. Taniyama, Y. Tokura, and S. Tarucha

PRL 107, 146801 (2011)



Outline

Introduction

Electron-spin resonance (ESR) and interdot exchange

Experimental setup

→ Single-spin rotation + swap gate

Control of entanglement

Conclusions


Introduction



Universal set of gates
$$U_{\text{CNOT}} = e^{i\pi S_L^z} U_s(\tau_s)^{-1/2} e^{-i(\pi/2)S_L^z} U_s(\tau_s) e^{i(\pi/2)S_L^z} U_s(\tau_s)^{1/2}$$

interdot spin exchange





Electron spin resonance (ESR) (Single-spin rotation)

Bloch Equation

$$\langle \dot{\mathbf{S}} \rangle = \langle \mathbf{S} \rangle \times (\omega_Z)$$


$$\omega_Z = g\mu_B \mathbf{B}/\hbar \quad \delta\omega(t) = g\mu_B \widetilde{B}_x \cos(\omega t)/\hbar$$


Spin precesses around axis defined by the direction of B,

Add external oscillating magnetic field $B_x(t)$ perpendicular to B_z

$$\langle \dot{\mathbf{S}} \rangle = \langle \mathbf{S} \rangle \times \left[\omega_Z - \omega \mathbf{e}_z + \frac{g\mu_B}{\hbar} \widetilde{B}_x \mathbf{e}_x \right]$$

$$\omega_{\rm R} = g\mu_B |B_z|/\hbar$$





Electric control of spins (EDSR)

Producing strong oscillating magnetic fields is very challenging




Electric control of spins is highly desirable


However, electric fields couple to the charge


indirect coupling to the spin

- Magnetic field gradient
- Spatially varying g tensor
- Spin-orbit coupling



Interdot exchange interaction






U: Coulomb energy

t₀: interdot tunneling controlled by central gate

$$H_s(t) = J(t)\mathbf{S}_L \cdot \mathbf{S}_R$$

$$J(t) \propto t_0^2(t)/U$$


$$U(t) = e^{-i/\hbar \int_0^t J(t')dt' \mathbf{S}_L \cdot \mathbf{S}_R}$$



$$U(\tau_s) \equiv \text{SWAP}$$

 J_0 : energy splitting between S(1,1) and $T_0(1,1)$


Experimental Setup



AlGaAs/GaAs heterostructure


Single-qubit rotations

J₀ finite




spin-blockade regime


vanishing J₀




Single-spin rotation τ_{EDSR}









$$g = -0.394 \pm 0.001$$


$$f_{\rm ac} = 5.6 \, GHz$$

$$\Delta B_0 = 15 \pm 5 \, mT$$


ε:energy splitting between S(0,2) and S(1,1)

Single-qubit rotations






averaged QPC signal is proportional to probability of having antiparallel spins




Two-Qubit Gate

J₀ finite




$$T_{\pm}(1,1) \stackrel{3\pi/2}{\longrightarrow}$$

vanishing J₀





$$\frac{|\uparrow\rangle \pm i|\downarrow\rangle}{\sqrt{2}} \otimes |\uparrow\rangle$$

J₀ finite




$$\xrightarrow{\text{SWAP}} |\psi_1\rangle \xrightarrow{\pi/2}$$





Two-Qubit Gate




$$SWAP^{n=0,2,4...} \to |\psi_2\rangle = T_+(1,1)$$



current is blocked

SWAP^{n=1,3,5,...}
$$\rightarrow |\psi_2\rangle = \frac{1}{2} [T_+(1,1) + T_-(1,1) - \sqrt{2}iS(1,1)]$$



do not contribute to the current flow

Readout is a direct measurement of entanglement

$$P_S = |\langle S|\psi_2\rangle|^2$$

Entanglement Control


$$C(\rho) = \max(0, \lambda_1 - \lambda_2 - \lambda_3 - \lambda_4)$$

$$\sqrt{\sqrt{\rho}\widetilde{\rho}\sqrt{\rho}} \quad \widetilde{\rho} = (\sigma_y \otimes \sigma_y)\rho^*(\sigma_y \otimes \sigma_y)$$

C=0: uncorrelated

C=1: maximally entangled

$$\Delta \equiv \delta E_Z/J_0 \quad \alpha \equiv J_0 \tau_{\rm ex}/2$$



$$C = \frac{|\sin\sqrt{1 + \Delta^2 \alpha}|}{1 + \Delta^2} \times \sqrt{(1 + \Delta^2)\cos^2\sqrt{1 + \Delta^2 \alpha} + \Delta^2 \sin^2\sqrt{1 + \Delta^2 \alpha}}$$

Control of degree of entanglement with τ_{ex}

Conclusions

All-electrical controlled two-qubit gate

Single spin rotation + interdot spin exchange

Control of entanglement through operation time t

Important step in the realization of a quantum computer

Thank you for your attention!